

PIPER AIRCRAFT, INC.
PA-46-500TP, MALIBU MERIDIAN
MAINTENANCE MANUAL

CHART 1
STRUCTURAL LIFE LIMITS

Serial Number Effectivity	Structural Component	Life Limit (Flight Hours)
4697001, 4697003 and up	Pressurized Structure • Fuselage Assembly - P/N 89600-004	10,145
4697001, 4697003–4697156	Wing, Wing Carry-Through, & their Attaching Structure • Wing Assembly - P/N 89640-004/-007 or 106898-002	13,349
	Horizontal Stabilizer • Horizontal Stabilizer Assembly - P/N 102050-002	13,349
	Vertical Fin • Vertical Fin Assembly - P/N 83401-008	13,349
4697001, 4697003–4697156 with Kit No. 767-360 installed	Wing, Wing Carry-Through, & their Attaching Structure • Wing Assembly - P/N 89640-007 or 106898-002	10,255
	Horizontal Stabilizer • Horizontal Stabilizer Assembly - P/N 102050-002	10, 255
	Vertical Fin • Vertical Fin Assembly - P/N 83401-008	10, 255
4697157–4697173	Wing, Wing Carry-Through, & their Attaching Structure • Wing Assembly - P/N 89640-007 or 106898-002	10,255
	Horizontal Stabilizer • Horizontal Stabilizer Assembly - P/N 102050-002	10, 255
	Vertical Fin • Vertical Fin Assembly - P/N 83401-008	10, 255
4697174–4697398, less 4697340	Wing, Wing Carry-Through, & their Attaching Structure • Wing Assembly - P/N 89640-008 or 106899-002/-003	10,255
	Horizontal Stabilizer • Horizontal Stabilizer Assembly - P/N 102050-002	10, 255
	Vertical Fin • Vertical Fin Assembly - P/N 83401-008	10, 255